
Extrapolation of Missing Craniofacial Skeletal Structure via Statistical Shape Models Project #1 Mini-Checkpoint Presentation EN.600.646 Spring 2014



CT Image Source: The Cancer Imaging Archive

Robert Grupp

Hsin-Hong Chiang

Dr. Yoshito Otake (Mentor)

Ryan Murphy (Mentor)

Dr. Russell Taylor (Mentor)

Dr. Mehran Armand (Mentor)












Project Goal

 Design and implement a method for extrapolating missing anatomical craniofacial skeletal structure with the use of a statistical shape model of the human cranium.



CT Image Source: The Cancer Imaging Archive














Project Relevance: Face Transplant Surgery

- Restore lost functionality
- Restore appearance




















Project Relevance: Face Transplant Surgery (cont.)




















Extrapolation Overview













Deliverable Status From Last Checkpoint

Minimum

- Segmentation mask of the skeletal regions in the cranial CT images
- Deformable registration of each CT image (or mesh) to a chosen template
- Atlas creation and evaluation (near completion)
- Development and evaluation of anatomical extrapolation method

Expected

- Creation and evaluation of an atlas via a bootstrapping technique
- Development of a realistic patient "disfigurement"

Maximum

- Design of a method to use the estimated surface of the patient to assist in surgical planning
- Create a system architecture for the future use of this system












Minimum Deliverables: Segmentation, Deformable Registration



Show in Slideshow mode for Animations

CT Image Source: The Cancer Imaging Archive













Principle Component Analysis Skin Modes



Mode 2 mean +0.00 std. dev 60 40 20 -20 -40 -40 -20 20 mean +0.00 std. dev. 60 40 20 0 -20



Show in Slideshow mode for Animations

CT Image Source: The Cancer Imaging Archive

40

20







-40

-20

20


60



-40



Leave-One-Out Skin Atlas Analysis

















Leave-One-Out Skin Surface Distances By Modes Used









Show in Slideshow mode for Animations

CT Image Source: The Cancer Imaging Archive











Deliverable Status From Last Checkpoint

Minimum

- Segmentation mask of the skeletal regions in the cranial CT images
- Deformable registration of each CT image (or mesh) to a chosen template
- Atlas creation and evaluation (Skin complete)
- Development and evaluation of anatomical extrapolation method

Expected

- Creation and evaluation of an atlas via a bootstrapping technique
- Development of a realistic patient "disfigurement"

Maximum

- Design of a method to use the estimated surface of the patient to assist in surgical planning
- Create a system architecture for the future use of this system












- Out of 26 meshes choose one to leave out
- Apply "disfiguration" to left-out mesh



CT Image Source: The Cancer Imaging Archive







Biomechanical- and Image-guided Surgical Systems



Deliverable Status From Last Checkpoint

Minimum

- Segmentation mask of the skeletal regions in the cranial CT images
- Deformable registration of each CT image (or mesh) to a chosen template
- Atlas creation and evaluation (Skin complete)
- Development and evaluation of anatomical extrapolation method

Expected

- Creation and evaluation of an atlas via a bootstrapping technique
- Development of a realistic patient "disfigurement"

Maximum

- Design of a method to use the estimated surface of the patient to assist in surgical planning
- Create a system architecture for the future use of this system












Apply random rigid transformation to disfigured, left-out, mesh



CT Image Source: The Cancer Imaging Archive








Collabortive Laboratory for BIGSS

Biomechanical- and Image-guided Surgical Systems



- Create an atlas with the remaining 25 complete meshes
- Perform patient-to-atlas registration



CT Image Source: The Cancer Imaging Archive








Collabortive Laboratory for BIGSS

Biomechanical- and Image-guided Suraical Systems



Surface distance of registered atlas instance and the true surface



CT Image Source: The Cancer Imaging Archive








Collabortive Laboratory for BIGSS

Biomechanical- and Image-guided Surgical Systems



 Replace the "disfigured" vertices in the patient mesh with the estimates from the atlas



CT Image Source: The Cancer Imaging Archive









BIGSS

Biomechanical- and Image-guided
Suraical Systems







CT Image Source: The Cancer Imaging Archive








Collabortive Laboratory for
BIGSS

Biomechanical- and Image-guided
Surgical Systems



Surface distance of extrapolated surface and the true surface



CT Image Source: The Cancer Imaging Archive







Collabortive Laboratory for BIGSS

Biomechanical- and Image-guided Surgical Systems



Deliverable Status From Last Checkpoint

Minimum

- Segmentation mask of the skeletal regions in the cranial CT images
- Deformable registration of each CT image (or mesh) to a chosen template
- Atlas creation and evaluation (Skin complete)
- Development and evaluation of anatomical extrapolation method (In Progress)

Expected

- Creation and evaluation of an atlas via a bootstrapping technique (In Progress)
- Development of a realistic patient "disfigurement"

Maximum

- Design of a method to use the estimated surface of the patient to assist in surgical planning
- Create a system architecture for the future use of this system












Test Patient CT



CT Courtesy of Dr. Chad Gordon












Test Patient Head Surface





CT Courtesy of Dr. Chad Gordon












Pruning of "Non-Original" Bone



CT Courtesy of Dr. Chad Gordon














Patient-to-Atlas Registration







Full Skull Atlas (26 Patients)

Atlas Estimate

CT Courtesy of Dr. Chad Gordon and TCIA












Atlas Estimate Deviation From Current Patient



CT Courtesy of Dr. Chad Gordon and TCIA












Updated Task Schedule From Last Checkpoint














Newly Updated Task Schedule














Newly Updated Task Schedule













Questions?









